



Moisture & Sound Underlayment

Product Specifications

- ~ Item #: LNG3N1
- ~ 3mm Thick
- ~ Blue EPE (Expand Aple Poly Ephykene) Construction
- ~ .04 mm Polyethylene Film Moisture Barrier Attached
- ~ Self-sealing Overlap Tape Strip Attached
- ~ Reduces ambient noise transmission
- ~ 100 square foot rolls

Installation:

- 1) Roll out 3 in 1 Underlayment on a Dry, Clean, and Flat Subfloor
- 2) Put the tape side to the wall, then roll underlayment over subfloor with vapor barrier down against the subfloor.
- 3) Roll the foam out with the next row butting the foam to the previous row.
- 4) Remove tape strip and place the overlapping poly film to the tape strip creating a moisture barrier. Any tears in the foam under should be taped creating a barrier.
- 5) After all underlayment is laid, Install you floor according to the manufacturers instructions.

Distributed By:
Crescent Hardwood Supply, Inc
1101 Sams Avenue
Harahan, LA 70123
Phone: 504-309-6950 Fax: 504-309-6949
www.lockandgoflooring.com

3 in 1 Underlayment